

## Insructions for Installing Repair Kit on Duraline Style Control Valves

- 1. Remove handle(5) from stem(3) by pulling in an outward direction.
- 2. Unscrew cap(6) from valve body(7).
- Pull stem(3), threaded insert(1), stem seal(4) and shut off seal(2) from valve body(7). Discard.
- 4. Insert new repair kit(8) into valve body(7) alighing the male keys and female keyways.
- 5. Screw cap(6) partially onto valve body(7). Do not tighten.
- 6. Turn stem(3) counter-clockwise until stop.
- 7. Tighten cap(6) firmly on to valve body(7) while adjusting the stem to a nuetral position, neither fully open nor fully closed.
- 8. Replace handle(5) on to stem(3)aligning the flats on the stem. Push firmly until stop.

Renewable Cartdrige						
P/N DL-RC-PVD						

NO.	PART NUMBER			
1	NV-T5TPI-X			
2	DL-SS-PTFE			
3	NV-N-5TENCAP	1		
4	NV-S-PTF (SSI Modified)			
5	Rotary Knob MQ			
6	NV-C-X	1		
7	Duraline Valve Globe Body	1		
8	DL-IDDI-ABS	1		

	Designer		5/14/2015	TITLE:			
	Review				Repair kit installation instructions for Duraline stlye control valves		
	Engineer			for Duraline stlye control valves			
				DWG. NO.			REV
	MARQUEST S C   E N T   F   C			BULLETIN-DDRK			
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES	I 2950 Airway Avenue, Costa Mesa, CA 92626 I		SCALE: N/A	Format: SD	SHEE	T 1 OF 1	

5 4 2